

Benches

Activating the Add Benches option will set adjacent lateral non-ore voxels adjacent to ore voxels within the specified Width to a mined waste classification. This will provide space for mining equipment to extract the ore. Note: Adding benches will increase the overall stripping ratio.

